



# **SnowDog™ Snowplow Headlight Adapter**

## INSTALLATION INSTRUCTIONS

### **16071150**

HB3/HB4 - GM 1999+

### **INSTRUCTIONS**

- 1.** Disconnect both PS and DS side truck headlights from the truck harness.
- 2.** Connect the 16071150 adapters to the OEM headlight connectors and truck harness connectors.
- 3.** Connect the 16071150 adapters to the universal light harness connectors included with the snowplow. This is part of the harness with the relay module.
- 4.** Use an included Tap connector to tap the BROWN wire into your PARK light circuit on both the PS and DS circuits.
- 5.** Use an included Tap connector to tap the PURPLE or ORANGE wire into the TURN light circuit on both the PS and DS circuits.
- 6.** Check all light functionality before operating the plow.