

SnowDog™ Snowplow Headlight Adapter

INSTALLATION INSTRUCTIONS

16071170

HB3/HB4 - GM 2004+ COLORADO/CANYON SWITCHED POWER/GROUND

INSTRUCTIONS

1. Disconnect both PS and DS side truck headlights from the truck harness.
2. Connect the 16071170 adapters to the OEM headlight connectors and truck harness connectors.
3. Connect the 16071170 adapters to the connectors on the RELAY HARNESS that came with the snowplow harness kit.
4. Use an included Tap connector to tap the BROWN wire into the PARKING light circuit on both the PS and DS circuits.
5. Use an included Tap connector to tap the PURPLE wire into the TURN light circuit on both the PS and DS circuits.
6. Connect the RED wire to a 12V FUSED power source
7. Connect the BLACK wire to a chassis or lighting circuit ground
8. Check all light functionality before operating the plow.

